

PROGRAMMING FACTORY SETTINGS, BALL & COIN COUNT (PT-6, PT-7 & PT-8).

NOTE:

The ball switch of the cage that you want to program must be activated during programming. This can be accomplished by holding down the ball count micro switch. Any cage that has the ball switch activated will have its cage number changed also.

(STEP 1) "Reprogram factory default settings"

Press "Clear"
Enter "3" "1"
Enter "1" "2" "3" "4"
Enter "2" "5" "5"
Press "Rent A"
Enter one of the following "1" "7" "6" - For a standard coin box or a single machine with card reader.
"1" "7" "7" - For a stand alone S.A.
"1" "8" "1" - For a dual machine with card reader.
Press "Rent B"
Activate the ball count micro switch
Press "Send"
Deactivate the ball count micro switch
Press "#"

(STEP 2) "Program cage number"

Press "Clear"
Enter "3" "1"
Enter "1" "2" "3" "4"
Press "Clear"
Enter the cage number "1-30"
Press "*" "
Activate and hold the ball count micro switch
Press "Send"
Deactivate the ball count micro switch
Press "#"

(STEP 3) "Program the ball & coin count"

Press "Clear"
Enter "3" "1"
Enter "1" "2" "3" "4"
Enter the number of coins required to start a game "1 - 100"
Press "Rent A"
Enter the number of balls per game "1 - 255"
Press "Rent B"
Press "Send"
Press "#"