


DANGER

HOPPER | BALL LOADING

1. Power must be turned off before picking up balls or loading hopper with balls.
2. When loading, employees should sound warning for batters to leave batting stalls during maintenance of equipment.
3. Batting helmets with face guards should be used at all times when maintaining equipment.
4. Always unplug power to I.H.S. unit when servicing.
5. Never put more than 400 baseballs or 300 softballs in main hopper at one time.
6. Never put more than 200 baseballs in secondary hopper at one time.
7. Please review batting range safety and operations standards located in your owners manual before using equipment.



Questions about this procedure? Give us a call at (800)854-3140 or (503)304-8899.