

PROGRAMMING 8 OR 10 CAGE OPERATION

(NOTE: This programming requires the new 102C and 103C card.)

If you have any other version than the “C” cards please refer to page 58 for 101 Card Usage Instructions.

1. Set **“PROGRAM”** switch to **“ON”**.
2. Press **“RUN”** to display cage select.
3. Press **“8”** to select 8 cage program or **“0”** for 10 cage program.
4. Set **“PROGRAM”** switch to **“OFF”** and you are finished.

10108 Will be displayed for 8 cage program.

10110 Will be displayed for 10 cage program.